


How to Replace the Side Panel on an ILVE Panoramagic Range



Replacing Your Side Panel:

Whether you're updating your ILVE Panoramagic range or replacing a damaged panel, this guide walks you through each step to ensure a clean and correct installation.

Ideal for technicians, contractors, or hands-on homeowners, this tutorial ensures the panel is replaced safely and efficiently.

Tools Required:

- Flathead screwdriver
- Phillips screwdriver or drill with proper bit
- Replacement side panel
- Clean, stable work surface

How to Replace the Side Panel on an ILVE Panoramagic Range



Step-by-Step Replacement

Step 1: Remove external screws.

Start by unscrewing the three screws that hold the side panel in place externally.

Step 2: Remove press-fit rivets.

Use a flathead screwdriver to remove the two press-fit rivets.

Step 3: Remove drawer and open oven door.

Slide the bottom drawer out and open the oven door for access.



Step 4: Unscrew internal panel screws.

Locate and remove the two screws inside that secure the side panel.

Step 5: Release the old panel.

Apply forward pressure to detach and remove the old panel.



Step 6: Align and insert new side panel.

Carefully align the new panel to ensure all holes and edges are flush.

Step 7: Reinstall screws and rivets.

Fasten the two internal screws, three external screws, and reinstall the press-fit rivets.

How to Replace the Side Panel on an ILVE Panoramagic Range



Step 8: Return the drawer to its position.
Slid the drawer back in to complete the process.

Final Recommendations

- Refer to the full ILVE Installation Manual for clearance requirements and connection guidelines.
- Always hire a licensed professional for gas and electrical installations.
- Register your ILVE Range online to activate your warranty and receive product support.

Need further assistance? Visit us.ilve.com or contact our support team.

